



## Postside Handrail Bracket

Postside Handrail Brackets are used when a handrail terminates into the side of a post (most commonly H or I posts). Your system may or may not use them depending on your layout. If you do have one, here's how to install it:

1. Slide the provided lock washer onto the allen bolt. Insert them through the pre-drilled 1/2" hole on your post and out the pre-drilled 1/4" hole on the opposite face.
2. Thread the dome onto the bolt until it is tight, using the Allen Wrench to position and support the bolt.
3. Use a rubber mallet to push the plug into the 1/2" hole on the back side of the post.
4. Adjust the bracket's location by moving the screw up and down the slots on the ears of the bracket. Continue this process until the bracket is positioned as needed.

