



# U-Shape Stringer Installation Guide



## Tools Needed from the Installation Kit



Torque Wrench



1/2" to 3/8" Reducer




3/4" Socket



5/16" Hex Bit Socket



5/16" Hanger Bolt Driver



T-10 & T-30 Torx Bits



ThreadLocker

## Other Tools and Supplies Not Included in the Installation Kit

- Drill/Hammer Drill
- Impact Driver/Socket Wrench
- Pencil
- Level
- T-Square
- 3/8" Wood Drill Bit (*Wood Install Only*)
- 9/16" Concrete Drill Bit (*Concrete Install Only*)
- 11/16" Forstner Bit (*Wood Install Only*)
- Wood Glue
- Concrete Epoxy (*Concrete Install Only*)
- Silicone Sealant

## Things to Know Before You Get Started


- Read over the provided material prior to the start of your installation
- Ensure to apply the supplied Threadlocker to all mechanical connections



## U-Shape Stringer Installation Steps



- Locate the stringers and measure them to make sure they match the prints provided to you during the engineering approval process



- Locate the stickers that indicate the “Foot” & “Head” sides of the stringer




- Identify and prepare the two halves of the hockey stick




- Using the access hole & the provided 1/2"-13 x 2" bolts, attach the two sides of each hockey stick
- Torque to 70 lb-ft


### U-Shape Stringer Installation Steps (Continued)




- Noting the “Foot” sticker, match the beveled Foot Plate holes to the Stringer holes



- Use the 1/2" x 2" Flathead Bolts to attach the floor plate to the stringer
- Torque to 70 lb-ft




- Slide the cover plate over the stringer, paying attention to its orientation
- The thin section will end up on top of the stringer




- Noting the “Head” sticker, match the beveled Header Plate holes to the Stringer holes
- Repeat Steps 5-6 for the Header Plate Bolts


### U-Shape Stringer Installation Steps (Continued)




- Use the provided drawing(s) to mark the wall & header plate dimensions
- At this point, mark a predrill location for the slotted hole in your header plate



- Predrill a single mounting hole with a 3/8" drill bit, for each plate




- Hoist the middle stringer into place
- We recommend using either a pulley system or a Come Along Winch and brace material to hold the stringer in place while fastening




- Fasten the 1/2" x 3 1/2" Hex Lag through the middle slotted hole in the header & footer plate to hold the stringer in place


### U-Shape Stringer Installation Steps (Continued)




- Hoist the upper stringer into place
- We recommend using either a pulley system or a Come Along Winch and brace material to hold the stringer in place while fastening



- Fasten the 1/2" x 3 1/2" Hex Lag through the middle slotted hole in the header plate to hold the upper stringer in place





- Using the 1/2" x 1" Flange Bolts, attach the upper stringer's lower plate to the middle stringer
- Torque to 70 lb-ft



- Hoist the lower stringer into place
- We recommend using either a pulley system or a Come Along Winch and brace material to hold the stringer in place while fastening
- Using the 1/2" x 1" Flange Bolts, attach the lower stringer's upper plate to the middle stringer
- Torque to 70 lb-ft

U-Shape Stringer Installation Steps (Continued)




Lower Stringer Floor Mount


- Predrill your footer plate holes with a 3/8" drill bit
- Thread the 1/2" x 5" head lags into place

Lower Stringer Floor Mount

- Drill 1/2" holes for the concrete wedge anchors
- Insert a concrete wedge anchor into each hole
- Torque to 50 lb-ft



- Place all tread brackets on the middle stringer
- Insert Christmas Tree Rivets to hold the tread brackets in place




- Thread the 1/2" x 1" flange bolts through the tread bracket and into the stringer in the marked order, so they are finger tight
- Torque to 70 lb-ft

## U-Shape Stringer Installation Steps (Continued)




- Place a single tread on to one of the tread brackets about half-way up the middle stringer



- Using the  $\frac{5}{16}$ " x  $2\frac{1}{2}$ " RSS Screws, attach the tread to the tread bracket
- During this step, alternate sides of the bracket when fastening screws - this will prevent the tread from pulling unevenly




- Ensure the tread is level on the tread bracket both front to back and left to right




- If not level left to right, shim the header plate to adjust
- If not level front to back, shim the footer plate to adjust
- Cut the excess shim away
- Predrill through the header plate holes with a  $\frac{3}{8}$ " drill bit
- At this point, predrill all your header plate holes using a  $\frac{1}{2}$ " bit

U-Shape Stringer Installation Steps (Continued)



- Repeat Steps 18-23 for the upper & lower stringers




- At this point you can predrill all your header plate holes
- Through Bolt**
- Predrill utilizing a 1/2" drill bit
- Lag Bolt**
- Predrill utilizing a 3/8" drill bit



**Lower & Upper Stringer Wall Mount**

- Thread the 1/2" x 8" hex head bolts into place
- Do this for both
- Slide the cover over the wall plates, you may want to use a dab of silicone on each of the bolts





**Lower & Upper Stringer Wall Mount**

- Refer to the recommendation of the brand of epoxy you are using and predrill the correct sized holes for these 1/2" threaded studs
- Apply concrete epoxy in to the holes
- Insert the threaded studs into each hole
- Allow for the appropriate amount of curing time, for the epoxy, based off of the manufactured recommendations
- Slide the cover over the wall plates, you may want to use a dab of silicone on each of the bolts



U-Shape Stringer Installation Steps (Continued)



Upper Stringer Header Mount (2 mounting styles)

**Through Bolt**

- Thread the 1/2" x 8" hex head bolts into place, so they are finger tight
- Torque to 70 lb-ft

**Lag Bolt**

- Thread the 1/2" x 5" head lags into place

Upper Stringer Header Mount

- Refer to the recommendation of the brand of epoxy you are using and predrill the correct sized holes for these 1/2" threaded studs
- Apply concrete epoxy in to the holes
- Insert the threaded studs into each hole
- Torque to 50 lb-ft




Upper Bracket Cover Installation

- Apply silicone sealant to the tops of the lags
- Carefully slide the cover over the wall plate

Lower Bracket Cover Installation

- Locate the lower bracket cover
- Apply silicon sealant to the tops of the lags or mounting hardware and install cover



- Using 5/16" - 18 x 1" mount & attach the Landing Plates
- Position the landing making sure that the platform lines up with the tread bracket and landing plates


U-Shape Stringer Installation Steps (Continued)



- Using the 5/16" x 2 1/2" RSS Screws, attach the platform to the landing plates
- During this step, alternate sides of the bracket when fastening screws - this will prevent the tread from pulling unevenly



- Next, identify your "first tread" on the lower stringer
- Using the 5/16" x 2 1/2" hanger bolts, populate the first tread holes



- Mount the first tread on to its tread plate
- The first tread mounts differently to the tread bracket than the rest of the treads




- Using a nut, tighten the tread to the tread bracket


### Switchback Stringer Installation Steps (Continued)




- Repeat Steps 20-22 to fasten the remaining treads, one at a time, onto the tread brackets



- Once your treads are in place, locate the tread bracket cover magnets and place all 4 magnets on the head of the magnet screws which are already factory installed (LED Treads will have 8 magnets)  
*Note: The magnets are strong enough to stick to the head of the screw and hold the tread bracket cover while the silicon (next step) dries.*
- The first tread will not typically receive a bracket cover and will not have the additional routing



- Next find your tread bracket covers and lay them out.
- Locate and prep your silicone tube
- Run a bead of silicone around the edge of the tread cover, or the edge of the routed section on the tread, whichever you prefer



- Set the bracket cover in place. The magnets in the treads will hold the cover tightly, and the silicone will prevent rattling and create a tight fit
- Wipe off any excess silicone that might squeeze out

## Congratulations! You're done with this section.

We'd love to see your work! Snap a few pics with your phone and send them to [pictures@viewrail.com](mailto:pictures@viewrail.com). Thanks for choosing Viewrail. Enjoy your new installation!